

┌ + ┐

SWITCH

—1—2—3—

D2 D1 D3

SW1 SW2 SW3

—GATE INPUT—

J15 J16 J17

—GATE OUTPUT—

J29 J30 J31

IN #1 IN #2

J37 J38

IN #3 3

J39 SW4 2

— 1 —

SHIFT

J1 J2



J20

OUT #1 OUT #2

J19 J42



┌ + ┐